WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 304-131-101 / 2003-2006 Infiniti G35 3.5L — CARB EO# N/A

Dragon Intake: 804-123-101 / 2003-2004 Nissan 350Z — CARB EO# D-489-2

Dragon Intake: 804-131-101 / 2003-2004 Infiniti G35 3.5L — CARB EO# N/A

Dragon Intake: 804-123-101 / 2005-2006 Nissan 350Z — CARB EO# N/A

Dragon Intake: 804-131-101 / 2005-2006 Infiniti G35 3.5L — CARB EO# N/A

Parts : 1 x Weapon*R 3.5" Intake Pipe / 1 x Weapon*R 4" Air Filter / 2 x 3"-3.5" Coupler / 1 x 3"-4" Coupler
1 x Intake System Bracket Kit / 3 x 3" Clamp / 3 x 4" Clamp / 1 x Blank MAF Adapter Plate with 4 bolts

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Disconnect the 15mm PCV hose from the OEM intake.
3. Unplug the MAF sensor, remove it from the OEM intake, and set it aside.
4. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
5. Install the 3"-3.5" coupler on the throttle body. Tighten with the OEM clamp.
6. Insert the Weapon*R intake pipe into the 3.5" side of the coupler. Tighten with a clamp.
7. Connect the OEM 15mm hose to the Weapon*R intake pipe.
8. Install the 3"-3.5" coupler on the end of the Weapon*R 3.5" tube.
9. Insert the MAF sensor into the 3.5" side of the Weapon*R coupler. Tighten the clamp.
10. Mount the MAF bracket on the OEM MAF with the 4 supplied bolts (on some cars you may need to drill holes to match the bolt pattern).
11. Install the 3"-4" coupler on the Dragon or Secret Weapon air filter. Tighten with the supplied clamp.
12. Install the filter assembly on the MAF bracket plate. Tighten with the OEM clamp.
13. Place the U-shaped end of the bracket under the clamp on the air filter.
14. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
15. Bend the straight end of the bracket to meet the rubber mounting grommet.
16. Secure with the washer and nut from the bracket kit.
17. Position the intake pipe so it does not touch any part of the vehicle.
18. Check hood clearance. Adjust the intake tube for the best fit and clearance.
19. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: 804-131-101 includes a 15mm hose; the other kits reuse the OEM 15mm hose. Some 3.5" Dragon kits ship with 4 x 3" and 4 x 4" clamps.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.









Bracket Video

Air Filter Cleaning Video

Question & Product, Please refer to our website @ WWW.WEAPON-R.COM, Tel#650-877-8280