DISCLAIMER: NOT LEGAL FOR USE OR SALE IN CALIFORNIA ON POLLUTION CONTROLLED MOTOR VEHICLES.

WEAPON·R COMPETITION PRODUCTS®

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Dragon Intake : 807-123-101**

Application : **1991-99 Saturn 4cyl DOHC / 95-02 4cyl SOHC**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 10mm x 12" Hose/ 1 x 3"-3" Coupler**

1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp / 1 x AIT Sensor Grommet

1. Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
2. Disconnect and remove the PVC hose from OEM intake and engine.
3. Disconect AIT sensor harness from OEM airbox, remove AIT sensor from OEM airbox.
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
5. Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
6. Insert Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
7. Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
8. Install AIT sensor grommet onto the 15mm hole on Weapon*R intake pipe, insert AIT sensor, connect harness.
9. Install the hoses from their point of origin and onto the Weapon *R intake pipe.
10. Install the Weapon*R Hyper filter onto the end of the intake pipe.
11. Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
12. Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
13. Install U-shaped part of intake system bracket under the clamp on air filter.
14. Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
15. Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
16. Secure with washer and nut included in bracket kit.
17. Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
18. Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
19. Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE !
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.
After installation of intake. Start engine and idle until normal operating temperature. Do NOT rev engine until engine is properly warmed up. Failure to do so may cause check engine light to come on.





Oil, Coolant Tanks & more available for this vehicle , for more info check our website.

Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM, Tel#650-877-8280