WEAPON R

US Patent# US 7,263,961B2

Recommend filter cleaning intervals: 3000 miles

Dragon Intake: 807-158-101 / 1995-2001 Chevy Lumina 3.1L & 3.4L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1998-2003 Chevy Malibu 3.1L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1995-2003 Chevy Monte Carlo 3.4L	CARB EO# N/A
Dragon Intake: 807-158-101 / 2000-2003 Chevy Monte Carlo 3.8L	CARB EO# N/A
Dragon Intake: 807-158-101 / 2000-2005 Chevy Impala 3.4L & 3.8L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1994-1998 Oldsmobile Achieva 3.1L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1995-1996 Oldsmobile Cutlass Ciera 3.1L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1988-2003 Pontiac Bonneville 3.8L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1994-1997 Pontiac Grand Am 3.1L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1999-2005 Pontiac Grand Am 3.4L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1997-2004 Pontiac Grand Prix 3.8L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1994-2003 Buick Century 3.1L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1992-2003 Buick LeSabre 3.8L	CARB EO# N/A
Dragon Intake: 807-158-101 / 1992-2003 Buick Regal 3.8L	CARB EO# N/A

Parts : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose 3 x 3 -3" Coupler / 1 x 3"-3.5" Coupler/ 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1 x Grommet

1. Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
2. Remove PCV hose from OEM intake and engine.
3. Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
5. Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
6. Insert Weapon*R intake pipe into the 3"-3" coupler, secure with clamp.
7. Vehicles with no MAF install 3"-3" coupler onto end of intake pipe, secure with clamp.
8. Vehicles MAF sensor install the 3"-3" coupler, secure with clamp.
9. Install the MAF into the 3'"-3" coupler clamp down
10. Vehicles with AIT sensors must drill 3/4" hole in side of tube for sensor grommet. Insert AIT into grommet.
11. Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
12. SOME VEHICLES MAY NEED TO USE THE 3"-3.5" COUPLER ON THEIR THROTTLE BODY, OR MAF SENSOR

13 **MODELS WITH ECU IN OEM AIRBOX. REMOVE ECU FROM AIRBOX AND LAY DOWN ECU. IT's OK TO LAY ECU DOWN**

14 **Install the 3"-3" coupler onto WR filter , secure with supplied clamp.**

15 **Install filter assembly onto the end of MAF sensor, secure with OEM clamp.**

16 **Install U-shaped part of intake system bracket under the clamp on air filter.**

17 **Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.**

18 **Bend the intake bracket to the Rubber mounting grommet ,secure w / washer, nut onto closest firm surface.**

19 **Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.**

20 **Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.**

21 **Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)**

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: **WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Note: **Returned Products may be subject to a 25% restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

After installation of intake. Start engine and idle until normal operating temperature. Do NOT rev engine until engine is properly warmed up. Failure to do so may cause check engine light to come on.

1994-03 Aurora V8 4.0L installed pictured

Oil, Coolant Tanks available, Product & Question visit us @ WWW.WEAPON-R.COM, Tel#650-877-8280







Bracket Video

Air Filter Cleaning Video

Question & Product, Please refer to our website @ WWW.WEAPON-R.COM, Tel#650-877-8280