

Secret Weapon: #301-179-101 / 17- 26 Honda Civic 1.5L Turbo

Parts List : 2 x Weapon®R Intake pipe. / 1 x Weapon®R Air Filter / 1 x 10MM Black Intake Bracket Bushing
2 x 2.5"-2.5" Coupler / 1 x 2.5"-3" coupler/ 1 x Intake System Bracket kit / 4 x 3" clamp

- 1 Loosen the OEM airbox and rubber intake tube, disconnect the MAF sensor harness from OEM airbox
- 2 Carefully remove the MAF sensor from the OEM airbox, remove the rubber intake tube and OEM airbox
- 3 Place the 2.5"- 2.5" coupler onto the Inlet manifold and secure with the clamp.
- 4 Place Short Weapon®R Intake Tube into the 2.5" end of the coupler and secure with clamp.
- 5 Install 2.5"-2.5" Coupler onto end of Weapon-R pipe and clamp down
- 6 Install the MAF sensor onto the Weapon-R intake pipe, secure with OEM screws
- 7 Install Cold air Pipe and lower to bottom then push into 2.5"-2.5" Coupler and clamp down
- 8 Remove under panelling to acces where the cold air pipe end is to install filter, Install 2.5"- 3" Coupler onto WR Filter
- 9 Insert the Weapon®R filter into the intake pipe, secure with clamp.
- 10 Install filter assembly onto the end of Weapon®R intake pipe, secure with OEM clamp.
- 11 Install U-shaped part of intake system bracket into under frame (pictured)
- 12 Install the rubber mounting grommet to the hole to the Weapon®R air filter.
- 13 Install the straight portion of the intake system bracket to the Rubber mounting grommet.
- 14 Secure with washer and nut included in bracket kit.
- 15 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 16 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 17 Place Weapon®R CARB Sticker on a visible place in engine compartment. (If Applicable)

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned Products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE !

Report any defective or missing parts to the authorized Weapon®R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

Note: After installation of intake. Start engine and let the car idle until the proper operating temperature before driving.

Do not rev engine until the engine has properly warmed up. Failure to do so may cause a check engine light to come on.

