

Secret Weapon: 301-152-101 / 1991-96 Acura NSX V6

Dragon Intake: 801-152-101 / 1991-96 Acura NSX V6

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Secret weapon 3" Air Filter / 1 x 10mm x Hose
1 x 4mm x hose/ 2 x 3"-3" Coupler / 1 x Intake System Bracket kit / 4 x 3" clamp

- 1 Loosen the OEM airbox and rubber intake tube, disconnect 4m and 10 mm vacume lines from OEM tube.
- 2 Carefully pull out the OEM hardline from the OEM intake tube.
- 3 Remove OEM airbox , and rubber intake tube as one.
- 5 **OPTION:** To remove the dual hardline you will need to bypass the coolant line.
- 6 To do so connect a hose from the engine block to the throttle body therefore bypassing the hardline.
- 7 Wipe down inside throttle body to remove all dirt.
- 8 Install 3"-3" coupler onto throttle body and clamp down 3"side.
- 9 Install WR pipe into the 3." side and clamp down with 3" clamp
- 10 Install 3" -3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned Products may be subject to a restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

Note: After installation of intake. Start engine and let the car idle until the proper operating temperature before driving.

Do not rev engine until the engine has properly warmed up. Failure to do so may cause a check engine light to come on.



Question about this Product, Tech assistance @ Tel#650-877-8280 / WEAPON-R.COM