WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 303-123-101 / 03-05 Mitsubishi Lancer Evolution Turbo — CARB EO#: D-489-3

Secret Weapon: 303-123-101 / 06 Mitsubishi Lancer Evolution Turbo — CARB EO#: N/A

Dragon Intake: 803-123-101 / 2003 - 2006 Mitsubishi Lancer Evolution Turbo — CARB EO#: N/A

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 4" / 1 x 8mm Hose / 1 x 4mm Hose / 1 x 1" Hose / 1 x 3" Coupler 1 x 2.5"-3" / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x 4"-4" Coupler / 2 x 4" Clamp / 1 x AFM Adapter

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Disconnect and remove the PCV hose from the OEM intake and engine.
3. Disconnect the original blow-off valve line and set it aside.
4. Disconnect the 4mm air check valve line from the air box and set it aside.
5. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
6. Wipe any grease off the turbo inlet. Install the 2.5"-3" coupler on the turbo inlet and tighten with the OEM clamp.
7. Insert the Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler. Tighten with a clamp.
8. Connect the OEM 4mm line from the air check valve to the port on the Weapon*R intake tube.
9. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
10. Use the supplied 1" silicone hose to reconnect the OEM blow-off valve.
11. Install the 3" coupler on the end of the Weapon*R intake pipe. Tighten the clamp.
12. Insert the AFM into the end of the 3" coupler. Tighten the clamp.
13. Bolt the Weapon*R MAF adapter to the OEM MAF sensor with the 4 supplied nuts and bolts.
14. Install the 4" coupler on the Secret Weapon air filter. Tighten with the supplied clamp.
15. Install the filter assembly on the end of the Weapon*R MAF plate. Tighten with the 4" clamp.
16. Place the U-shaped end of the bracket under the clamp on the air filter.
17. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
18. Bend the straight end of the bracket to meet the rubber mounting grommet.
19. Secure with the washer and nut from the bracket kit.
20. Position the intake pipe so it does not touch any part of the vehicle.
21. Check hood clearance. Adjust the intake tube for the best fit and clearance.
22. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE! Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from. Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving. Do not rev the engine until it is fully warmed up, or the check engine light may come on.





