WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 303-128-101 / 2004-2008 MITSUBISHI Galant 2.4L MIVEC — CARB EO#: N/A

Dragon Intake: 803-128-101 / 2004-07 Mitsubishi Galant 4 Cyl 2.4L MIVEC — CARB EO#: N/A

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 8mm Hose / 1 x 3" Coupler
1 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

1. Remove the three 10mm bolts holding the resonator.
2. Remove the one 10mm bolt at the front of the air box and the two plastic pop fasteners holding the air scoop.
3. Disconnect the PCV hose from the intake hose.
4. Loosen the clamp on the throttle body.
5. Remove the resonator and air scoop, then remove the air box and hose together.
6. Unbolt the MAF sensor from the OEM air box and set it aside for later.
7. Wipe the inside of the throttle body clean of any oil or dirt.
8. Install the 3"-3" coupler on the throttle body and tighten with the OEM clamp.
9. Insert the Weapon*R intake pipe into the coupler and tighten with the supplied clamp.
10. Insert the MAF sensor into the Weapon*R intake pipe, noting the airflow direction on the sensor.
11. Secure the sensor to the pipe with the supplied hardware and reconnect the sensor wire.
12. Install the 2.5"-3" coupler on the end of the Weapon*R intake pipe.
13. Thread the supplied rubber screw into the nearest 10mm hole.
14. Hook the supplied bracket onto the clamp and slide it onto the 3" side of the 2.5"-3" coupler.
15. Bend the bracket to reach the rubber screw, cut off any extra, and secure it to the rubber screw.
16. Insert the Weapon*R air filter into the coupler and tighten with a clamp.
17. Check all clamps and connections for leaks, and check clearance around the intake before driving.
18. Let the engine computer adjust for at least 5 minutes before revving the engine hard.

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.





