WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 304-111-101 / 1990-00 Sentra / Sentra SE-R / 1991-02 Infinity G20 / 1995-98 200SX 1.6L / 2.0L **CARB EO#: N/A**

Dragon Intake: 804-111-101 / 90-00 Sentra 1.6L **CARB EO#: D-489-2**

Dragon Intake: 804-111-101 / 90-00 Sentra 2.0L / SE-R / 91-02 Infinity G20 / 95-98 200SX **CARB EO#: N/A**

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter / 2 x 3" coupler / 2 x 9 mm silicone hose / 1 x 4mm silicone lines
1 x 2.5"-3" Coupler / 1 x Intake Bracket kit / 3 x 3" Clamp / 1 x AFM-NS Adapter plate

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Disconnect the 15mm PCV hose and the 10mm air recirculation hose from the OEM intake.
3. Unplug the MAF sensor and remove it from the intake.
4. Unplug the AIT sensor and remove it from the OEM air box.
5. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
6. Install the 2.5"-3" coupler on the throttle body. Tighten with the OEM clamp.
7. Insert the Weapon*R intake pipe into the coupler. Tighten with a clamp.
8. Connect the Weapon*R 9mm hose from the PCV port to the Weapon*R intake pipe.
9. Connect the other Weapon*R 9mm hose from the air recirculation valve to the Weapon*R intake pipe.
10. Install the 3" coupler on the end of the intake pipe. Tighten with a clamp.
11. Insert the MAF sensor into the 3" coupler. Tighten with a clamp and plug in the MAF.
12. Drill out the 9mm marked hole on the Weapon*R MAF adapter plate, then install the AIT sensor in it.
13. Line up the MAF holes with the AFM-NS adapter plate. Secure with the kit nuts and bolts.
14. Install the AIT sensor in the MAF adapter plate.
15. Install the 3" coupler on the Dragon or Secret Weapon air filter. Tighten with the supplied clamp.
16. Install the filter assembly on the AFM adapter plate. Tighten with the OEM clamp.
17. Place the U-shaped end of the bracket under the clamp on the air filter.
18. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
19. Bend the straight end of the bracket to meet the rubber mounting grommet.
20. Secure with the washer and nut from the bracket kit.
21. Position the intake pipe so it does not touch any part of the vehicle.
22. Check hood clearance. Adjust the intake tube for the best fit and clearance.
23. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.





