WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 305-121-101 / 2000-2005 TOYOTA CELICA GT	**CARB EO#: N/A**
Secret Weapon: 305-121-101 / 2000-2005 TOYOTA CELICA GTS	**CARB EO#: N/A**
Dragon Intake: 805-121-101 / 2000-2004 Toyota Celica GT	**CARB EO#: D-489-2**
Dragon Intake: 805-121-101 / 2000-2004 Toyota Celica GTS	**CARB EO#: D-489-2**
Dragon Intake: 805-121-101 / 2005 Toyota Celica GT	**CARB EO#: N/A**
Dragon Intake: 805-121-101 / 2005 Toyota Celica GTS	**CARB EO#: N/A**

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 10mm Hose / 1 x 2.5"-3" Coupler
1 x 2.75" -2.75 " Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp / 1 x 4mm Vacuum Cap

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Unbolt the Air Recirculator valve, move aside for later re-installation.
3. Remove PCV and all 4mm vacuum hoses from OEM intake and engine.
4. Unplug the MAF sensor and carefully remove it from the OEM air box.
5. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
6. Wipe the throttle body clean of any grease, install the 2.75" -3" coupler onto throttle body, secure with OEM clamp.
7. Insert the Weapon*R intake pipe into the 3" coupler. Tighten with a clamp.
8. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
9. Install the 4mm vacuum cap onto the 4mm port on the intake manifold, left behind by the OEM 4mm hoses.
10. Install MAF sensor into Weapon*R intake pipe, reconnect MAF sensor harness (sit facing downward on intake pipe)
11. Install air recirculator valve onto bracket on intake pipe with OEM screw.
12. Install the Weapon*R filter onto the end of the intake pipe.
13. Install 2.5"-3" coupler onto the intake pipe, secure with a clamp.
14. Insert Secret Weapon air filter into the coupler, secure with supplied clamp.
15. Place the U-shaped end of the bracket under the clamp on the air filter.
16. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
17. Bend the straight end of the bracket to meet the rubber mounting grommet.
18. Secure with the washer and nut from the bracket kit.
19. Position the intake pipe so it does not touch any part of the vehicle.
20. Check hood clearance. Adjust the intake tube for the best fit and clearance.
21. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).
Note: WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.







