US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 305-141-101 / 1992-1993 Toyota Camry	**CARB EO#: N/A**
Secret Weapon: 305-141-101 / 1992-1993 Lexus ES300 V6	**CARB EO#: N/A**
Dragon Intake: 805-141-101 / 1992-1993 Toyota Camry	**CARB EO#: D-489-2**
Dragon Intake: 805-141-101 / 1992-1993 ES300 V6	**CARB EO#: D-489-2**

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 10mm Hose / 3 x 3" Coupler
1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x 15mm Hose / 1 x AFM-TY Adapter Kit

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Remove PCV & Air Recirculator valve hose from OEM intake and engine.
3. Unplug the MAF sensor and carefully remove it from the OEM air box.
4. Loosen the nuts holding the MAF to the OEM air box and remove the MAF.
5. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
6. Wipe any grease off the throttle body. Install the 3" coupler on the throttle body and tighten with the OEM clamp.
7. Insert the Weapon*R intake pipe into the 3" coupler. Tighten with a clamp.
8. Measure the OEM PCV hose, replace with supplied 15mm hoses, install from PCV ports to intake pipe.
9. Install the 10mm hose onto the air recirculator valve and onto the Weapon*R intake pipe.
10. Install the 3" coupler on the end of the intake pipe. Tighten with a clamp.
11. Install MAF sensor into the 3" coupler, reconnect MAF sensor harness, secure with a clamp.
12. Line up the 4 holes on the MAF sensor with the AFM-TY adapter plate and install the plate on the MAF.
13. Install the 3" coupler on the Dragon or Secret Weapon air filter. Tighten with the supplied clamp.
14. Install the filter assembly on the end of the AFM adapter plate. Tighten with the OEM clamp.
15. Place the U-shaped end of the bracket under the clamp on the air filter.
16. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
17. Bend the straight end of the bracket to meet the rubber mounting grommet.
18. Secure with the washer and nut from the bracket kit.
19. Position the intake pipe so it does not touch any part of the vehicle.
20. Check hood clearance. Adjust the intake tube for the best fit and clearance.
21. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.







Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280