**US Patent# US 7,263,961B2**

**Recommended Air Filter Cleaning Intervals: 3000 Miles**

## Secret Weapon: 305-157-101 / 2007-2011 Toyota Yaris 1.5L — CARB EO#: N/A

## Dragon Intake: 805-157-101 / 2006-2011 Toyota Yaris 1.5L — CARB EO#: N/A

**Parts List :** 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 15mm Hose / 1 x 2"-2.5"Coupler
1 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Remove PCV hose from OEM intake and engine valve cover.
3. Unplug the MAF sensor and carefully remove it from the OEM air box.
4. Remove the air recirculator valve from the OEM intake tube.
5. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
6. Wipe the throttle body clean of any grease, install the 2"-2.5" coupler onto throttle body, secure with OEM clamp.
7. Insert Weapon*R intake pipe into the 2.5" coupler, secure with a clamp.
8. Measure the OEM PCV hose and replace it with the supplied 15mm hose, from the PCV port to the intake pipe.
9. Install the MAF sensor in the Weapon*R intake pipe and plug the MAF back in.
10. Install the 2.5" end of the 2.5"-3" coupler onto intake pipe, secure with supplied clamp.
11. Install filter assembly onto the end of Weapon*R intake pipe, secure with a clamp.
12. Install the rubber mounting grommet to the closest hole to the bracket on intake pipe.
13. Line up the bracket on the intake pipe to the rubber mounting grommet.
14. Secure with the washer and nut from the bracket kit.
15. Position the intake pipe so it does not touch any part of the vehicle.
16. Check hood clearance. Adjust the intake tube for the best fit and clearance.
17. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

**DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.**

**Note:** Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

**Note:** After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.








**Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280**