US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-124-101 / 2000-2002 Saturn 4cyl DOHC S-SERIES ONLY **CARB EO#: N/A**

Dragon Intake: 807-124-101 / 2000-2002 Saturn 4cyl DOHC S-SERIES ONLY **CARB EO#: N/A**

Parts List : 2 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter / 1 x 10mm Hose / 1 x 2.5" Coupler
1 x 2.5"-3" Coupler / 1 x 3"-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp
1 x AIT Sensor Grommet

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Disconnect and remove the PCV hose from the OEM intake and engine.
3. Unplug the AIT sensor and remove it from the OEM air box.
4. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
5. Wipe the throttle body clean of any grease, install the 2.5" coupler onto throttle body, secure with OEM clamp.
6. Insert the 90 degree Weapon*R intake pipe into the 2.5" coupler, secure with a clamp.
7. Install the 2.5"-3" coupler onto the end of the 90 degree intake pipe, secure with a clamp.
8. Install the 2nd Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with a clamp.
9. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
10. Install the AIT sensor grommet in the 15mm hole on the Weapon*R intake pipe. Insert the AIT sensor and plug it in.
11. Reconnect the hoses from their original ports to the Weapon*R intake pipe.
12. Install the 3" coupler on the Dragon or Secret Weapon air filter. Tighten with the supplied clamp.
13. Install the filter assembly on the end of the Weapon*R intake pipe. Tighten with the OEM clamp.
14. Place the U-shaped end of the bracket under the clamp on the air filter.
15. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
16. Bend the straight end of the bracket to meet the rubber mounting grommet.
17. Secure with the washer and nut from the bracket kit.
18. Position the intake pipe so it does not touch any part of the vehicle.
19. Check hood clearance. Adjust the intake tube for the best fit and clearance.
20. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.







Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280