WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-138-101 / 2002-2004 EXPLORER Sport trac V6 4.0L SOHC	**CARB EO#: N/A**
Secret Weapon: 307-138-101 / 2002-2003 EXPLORER 4.0L V6	**CARB EO#: N/A**
Dragon Intake: 807-138-101 / 2002-2004 EXPLORER Sport Trac V6 4.0L SOHC	**CARB EO#: N/A**
Dragon Intake: 807-138-101 / 2002-2003 EXPLORER 4.0L V6	**CARB EO#: N/A**

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 10mm Hose / 3 x 3"-3" Coupler
1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AFM PLATE BLANK

1. Remove bolts securing OEM air intake, and tube loosen clamps on OEM rubber intake pipe.
2. Remove PCV hose from OEM intake and engine.
3. Remove the OEM rubber intake tube.
4. Unplug mass air sensor, and Remove OEM air box lid with mass air sensor attached Unbolt mass air sensor from top of OEM air box, put aside.
5. Remove rest of OEM air box.
6. Wipe the throttle body clean of any grease, install the 3"-3" coupler onto throttle body, secure with OEM clamp.
7. Install the WR intake tube into 3" side of coupler and clamp down Take MAF and mark holes and drill to MAF bolt pattern, then bolt plate to MAF using supplied bolts.
8. Install 3"-3" to mass air unit and clamp down, then install 3" side of coupler to end of WR intake pipe.
9. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
10. Install the 3" coupler on the Dragon or Secret Weapon air filter. Tighten with the supplied clamp.
11. Install filter assembly onto the end of Weapon*R AFM plate, secure with OEM clamp.
12. Place the U-shaped end of the bracket under the clamp on the air filter.
13. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
14. Bend the straight end of the bracket to meet the rubber mounting grommet.
15. Secure with the washer and nut from the bracket kit.
16. Position the intake pipe so it does not touch any part of the vehicle.
17. Check hood clearance. Adjust the intake tube for the best fit and clearance.
18. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.







Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280