US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-174-101 / 2006-2007 Pontiac Solstice	CARB EO#: D-489-3
Secret Weapon: 307-174-101 / 2007 Saturn Sky 2.4L Ecotec	CARB EO#: D-489-3
Secret Weapon: 307-174-101 / 2008-2009 Pontiac Solstice	CARB EO#: N/A
Secret Weapon: 307-174-101 / 2008-2009 Saturn Sky 2.4L Ecotec	CARB EO#: N/A


Dragon Intake: 807-174-101 / 2006-2009 PONTIAC SOLSTICE 2.4L Ecotec	CARB EO#: N/A
Dragon Intake: 807-174-101 / 2007-2009 SATURN SKY 2.4L Ecotec	CARB EO#: N/A

Parts List : 2 x Weapon*R Intake pipe / 1 x Weapon*R 3" Air Filter / 1 x 10mm Hose / 1 x 2.75"-3"COUPLER
1 x 2.5"-3" Coupler / 2 x 3"-3" Coupler / 1 x Aluminum Elbow / 1 x Intake System Bracket kit
8 x WR Clamps

1. Loosen clamps securing OEM air cleaner tube.
2. Disconnect and remove the PCV hose from the OEM intake and engine.
3. Disconnect MAF sensor harness from OEM tube, remove MAF sensor from OEM intake tube.
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box.
5. Remove OEM air cleaner from front of vehicle.
6. Wipe the throttle body clean of any grease, install 2.5"-3" Coupler onto throttle body, secure with a clamp.
7. Install WR Aluminum Elbow Into 3" side of coupler on throttle body and clamp down.
8. Install MAF sensor into small WR pipe and secure.
9. Install small WR pipe into 3" coupler on WR aluminum elbow and clamp down.
10. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
11. Install 3"-3" coupler onto tube, 3" side to pipe.
12. Line up holes on Long WR pipe with frame of vehicle and use OEM grommet locations.
13. Install #2 Long WR pipe onto end of coupler and clamp down.
14. Install 3"-3" coupler onto end of #2 Long pipe.
15. Install Secret Weapon air filter onto the 3" side of coupler, secure with supplied clamp.
16. Reconnect MAF wire harness to sensor installed in pipe.
17. Position the intake pipe so it does not touch any part of the vehicle.
18. Check hood clearance. Adjust the intake tube for the best fit and clearance.
19. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES







Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280