WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-185-101 / 2000-2004 Chrysler 300M 3.5L V6 — CARB EO#: N/A

Dragon Intake: 807-185-101 / 2000-2004 Chrysler 300M 3.5L V6 — CARB EO#: N/A

Parts List : 2 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter 3" / 1 x 15mm Hose / 3 x 3"-3" Coupler
1 x Intake System Bracket kit / 6 x 3" Clamp / 1 x black rubber grommet

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Remove the PCV hose from the OEM intake and engine.
3. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
4. Remove the OEM air box attached to the stock rubber elbow near the throttle body.
5. Leave the OEM rubber 90 degree tube attached to the throttle body.
6. Wipe the OEM rubber 90 degree tube clean of any grease.
7. Insert 1st Weapon*R intake pipe into the OEM 90 degree elbow, secure with a clamp.
8. Install 3"-3" coupler onto end of 1st intake tube, clamp down.
9. Install the second WR intake tube into 3"-3" coupler and secure down with clamp.
10. Measure the OEM PCV hose and replace it with the supplied 15mm hose, from the PCV port to the intake pipe.
    Note: Secret Weapon Filter Option.
11. Install the 3"-3" coupler onto the end of the second WR intake pipe, secure with supplied clamp.
12. Install filter assembly onto the 3"-3" coupler, secure with a clamp.
13. Place the U-shaped end of the bracket under the clamp on the air filter.
14. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
15. Bend the straight end of the bracket to meet the rubber mounting grommet.
16. Secure with the washer and nut from the bracket kit.
17. Position the intake pipe so it does not touch any part of the vehicle.
18. Check hood clearance. Adjust the intake tube for the best fit and clearance.
19. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.







