US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 308-113-101 / 1994-2005 Mercedes 6 cyl. (SINGLE INTAKE INLET APPLICATION ONLY)	**CARB EO#: N/A**
Secret Weapon: 308-115-101 / 1990-2004 BMW 6 cyl	**CARB EO#: N/A**
Dragon Intake: 808-113-101 / 1994-2003 Mercedes 6 cyl. (SINGLE INTAKE INLET APPLICATION ONLY)	**CARB EO#: N/A**
Dragon Intake: 808-115-101 / 1990-2004 BMW 6 cyl	**CARB EO#: N/A**

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter / 3 x 3" Clamp / 1 x 3"-3.5" Coupler
1 x 2.5"-3" Coupler / 2 x 3" Coupler / 1 x Weapon*R Decal / 1 x Intake Bracket kit

1. Using tools remove stock air box and OEM Clamps, put aside for later use.
2. Place the 2.5"-3" Coupler onto the front of the Air Flow Meter and clamp down with the OEM clamp.
3. Place a supplied Stainless Steel Clamp onto the 3" end of the 2.5"-3" Reducer hose.
4. Place Weapon*R Intake Tube into the 3" end of Reducer hose and clamp down Stainless Steel Clamp.
5. Attach Weapon*R Filter to end of Weapon*R Intake Pipe, clamp down.
6. Install the 3" coupler on the intake pipe. Tighten with the supplied clamp.
7. Install the filter assembly on the end of the Weapon*R intake pipe. Tighten with the OEM clamp.
8. Place the U-shaped end of the bracket under the clamp on the air filter.
9. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
10. Bend the straight end of the bracket to meet the rubber mounting grommet.
11. Secure with the washer and nut from the bracket kit.
12. Position the intake pipe so it does not touch any part of the vehicle.
13. Check hood clearance. Adjust the intake tube for the best fit and clearance.
14. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.









Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280