WEAPON R

US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 348-111-101 / 1999-02 Daewoo Laganza

Dragon Intake: 848-111-101 / 1999-02 Daewoo Laganza

Parts List : 1 x Intake pipe / 1 x Air Filter / 1 x 15mm x 12" Hose / 2 x 3" coupler / 1 x AIT sensor grommet
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 6 x 3" Clamp / 1 x 3" Casted elbow

1. Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
2. Remove the PCV hose from from OEM intake and engine.
3. Unplug AIT sensor harness, remove AIT sensor from the OEM air cleaner box.
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
5. Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
6. Install 3" casted elbow onto 2.5"-3" coupler , install the 3" coupler onto elbow, secure with clamps.
7. Insert Weapon*R intake pipe into the 3" coupler on casted elbow, secure with clamp.
8. Install the AIT rubber grommet into the WR intake pipe, insert AIT sensor into grommet, connect harness.
9. Measure the OEM PVC hose, replace with supplied 15mm hose, install from PVC port to intake pipe.
10. Install the hoses from their point of origin and onto the Weapon *R intake pipe.
11. Install the Weapon*R Hyper filter onto the end of the intake pipe.
    Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
12. Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
13. Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
14. Install U-shaped part of intake system bracket under the clamp on air filter.
15. Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
16. Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
17. Secure with washer and nut included in bracket kit.
18. Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
19. Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
20. Place Weapon*R CARB Sticker on a visible place in engine compartment. **(If Applicable)**

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned Products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE !
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

Note: After installation of intake. Start engine and let the car idle until the proper operating temperature before driving.
Do not rev engine until the engine has properly warmed up. Failure to do so may cause a check engine light to come on.









Question about this Product Tel# 650-877-8280 / WEAPON-R.COM