US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 306-121-101 / 2011-2012 Subaru Impreza 2.5L (Non Turbo application only)

CARB EO#: N/A

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R Air Filter / 2 x 10mm Hose / 1 x 2.75"-2.75" coupler
1 x Intake System Bracket kit / 1 x 2.75"-3" Coupler / 4 x 3" Clamp

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Remove the PCV hoses from the OEM intake and engine.
3. Remove the OEM rubber intake tube. Lift the OEM air box straight up and out.
4. Remove MAF sensor from factory portion of air box and set aside for later install Wipe the throttle body clean of any grease, install the 2.75" coupler onto throttle body, secure with OEM clamp.
5. Insert the Weapon*R intake pipe into the 2.75" coupler. Tighten with a clamp.
6. Measure from valve cover PCV port to intake pipe ports Replace with supplied 10mm hoses.
7. Connect OEM 15mm Hose to WR 15mm port on pipe.
8. Use OEM 10mm Bolt and Secure WR pipe to OEM Intake bracket.
9. Reinstall MAF sensor into Weapon-R pipe and bolt down.
10. Install the 2.75"-3" coupler onto Secret Weapon air filter, secure with supplied clamp.
11. Install filter assembly onto the Weapon*R Intake Pipe, secure with a clamp.
12. Place the U-shaped end of the bracket under the clamp on the air filter.
13. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
14. Bend the straight end of the bracket to meet the rubber mounting grommet.
15. Secure with the washer and nut from the bracket kit.
16. Position the intake pipe so it does not touch any part of the vehicle.
17. Check hood clearance. Adjust the intake tube for the best fit and clearance.
18. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

Note: WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.





Intake System Bracket Video

Air Filter Cleaning Video

Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280