US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-169-101 / 2005-2006 Chevy Cobalt 2.0L Supercharged — CARB EO#: D-489-3

Secret Weapon: 307-169-101 / 2007 Chevy Cobalt 2.0L Supercharged — CARB EO#: N/A

Dragon Intake: 807-169-101 / 2005-2007 COBALT 2.0L SUPERCHARGED — CARB EO#: N/A

Parts List : 2 x Weapon*R Intake pipe / 1 x Weapon*R 3" Air Filter / 1 x 15mm Hose / 3 x 3"-3" Coupler
1 x Intake System Bracket kit / 6 x 3" Clamp

1. Loosen clamps securing OEM air cleaner tube.
2. Disconnect and remove the PCV hose from the OEM intake and engine.
3. Disconnect MAF sensor harness from OEM tube, remove MAF sensor.
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box.
5. Remove OEM air cleaner box from fender well.
6. Wipe the throttle body clean of any grease, install the 3"-3" coupler onto throttle body, secure with OEM clamp.
7. Insert #1 long Weapon*R intake pipe into the 3" end of the coupler, secure with a clamp.
8. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
9. Install 3"-3" coupler onto tube, 3" side to pipe.
10. Install #2 small WR pipe onto end of coupler from under the fender well of vehicle.
11. Install 3"-3" coupler onto end of #2 small WR pipe.
12. Install Secret Weapon air filter onto the 3" side of coupler, secure with supplied clamp.
13. Install U-shaped bracket on #2 WR pipe to bolt location on inner fender well.
14. Position the intake pipe so it does not touch any part of the vehicle.
15. Check hood clearance. Adjust the intake tube for the best fit and clearance.
16. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

DISCLAIMER: NOT LEGAL FOR SALE OR USE ON CALIFORNIA RESTRICTED AIR POLLUTION MOTOR VEHICLES.

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.









Intake System Bracket Video

Air Filter Cleaning Video