US Patent# US 7,263,961B2

Recommended Air Filter Cleaning Intervals: 3000 Miles

Secret Weapon: 307-157-101 / 2004-2006 Saturn ION 2.0L SUPERCHARGED

CARB EO#: D-489-3

Parts List : 1 x Weapon*R Intake pipe / 1 x Weapon*R 4" Air Filter / 1 x 10mm Hose / 2 x 3"-3.5" Coupler
1 x Intake System Bracket kit / 3 x 3" Clamp / 3 x 4" clamps, 1 x 3"-4" coupler

1. Remove the bolts holding the OEM air box. Loosen the clamps on the OEM rubber intake tube.
2. Disconnect and remove the PCV hose from the OEM intake and engine.
3. Disconnect MAF sensor harness from OEM tube, remove MAF sensor housing.
4. Remove the OEM rubber intake tube, remove the OEM air cleaner box.
5. Remove OEM air cleaner box on top of throttle body.
6. Wipe any grease off the throttle body. Install the 3"-3.5" coupler on the throttle body and tighten with the OEM clamp.
7. Insert Weapon*R intake pipe into the 3.5" end of the coupler, secure with a clamp.
8. Measure the OEM PCV hose and replace it with the supplied 10mm hose, from the PCV port to the intake pipe.
9. Install 3.5"-3" coupler onto tube, 3.5" side to pipe.
10. Install MAF housing into 3" side of coupler and clamp down.
11. Install 3"-4" coupler onto end of MAF housing 3" side to MAF.
12. Install Secret Weapon air filter onto the 4" side of coupler, secure with supplied clamp.
13. Place the U-shaped end of the bracket under the clamp on the air filter.
14. Install the rubber mounting grommet in the hole closest to the Weapon*R air filter.
15. Bend the straight end of the bracket to meet the rubber mounting grommet.
16. Secure with the washer and nut from the bracket kit.
17. Position the intake pipe so it does not touch any part of the vehicle.
18. Check hood clearance. Adjust the intake tube for the best fit and clearance.
19. Place the Weapon*R CARB sticker in a visible spot in the engine bay (if applicable).

Note: Returned products may be subject to a restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!
Report any defective or missing parts to the authorized Weapon*R dealer you bought this product from.
Installation requires some mechanical skill. We recommend having a qualified mechanic install it.

Note: After installing the intake, start the engine and let it idle to operating temperature before driving.
Do not rev the engine until it is fully warmed up, or the check engine light may come on.



Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM / Tel#650-877-8280